



Assembly Instructions

IMPORTANT

DO NOT RETURN THIS BATTING CAGE TO THE RETAIL STORE WHERE PURCHASED. **CALL TOLL FREE: (800) 492-9334**

IMPORTANT WARRANTY WARNING:

DO NOT LEAVE THIS NET ASSEMBLED DURING HEAVY WIND, SNOW, SLEET, OR ICE STORMS. THIS NET IS NOT DESIGNED TO WITHSTAND EXTREME WEATHER CONDITIONS AND DAMAGE TO THE FRAMES CAUSED BY EXTREME WEATHER MAY NOT BE COVERED IN THE MANUFACTURERS WARRANTY.


WARNING:

USE THIS PRODUCT WITH ADULT SUPERVISION ONLY. SERIOUS BODILY INJURY MAY OCCUR! READ WARNING LABELS CAREFULLY.




PARTS LIST

9 Piece Bungee and Spring Fiberglass Frame
(Comes with netting attached to frame)




2 - Ground Stakes

Poly Netting with
Red Target Area




STEP 1

Tap or push both Ground Stakes into ground 7 feet apart.
(Caution: Do not pound on the stake top. Damage could prevent
frame from inserting properly)



STEP 2

Assemble Fiberglass Frame by inserting each pole end
into the adjoining metal joint.
(Note: Make sure not to pinch the bungee cord)



STEP 4

Drape the Netting up and over the frame.

(Note: The Red rings should be on the top-side corners)

STEP 3

Insert each frame end into the Ground Stakes.

