

# *Heater*<sup>TM</sup> **Spring Away Pro** *Pop Up Net*

## ***Assembly Instructions***

### **IMPORTANT**

DO NOT RETURN THIS SPORTS NET TO THE RETAIL STORE WHERE  
PURCHASED. **CALL TOLL FREE: (800) 492-9334**

### **WARNING:**

THIS ITEM IS DESIGNED TO POP OPEN AND SNAP CLOSE QUICKLY. DO NOT ALLOW SMALL CHILDREN TO  
FOLD OR UNFOLD WITHOUT ADULT SUPERVISION!

READ WARNING LABELS CAREFULLY.

Never allow anyone to be behind the net in any possible path of the ball should the ball go through the netting. Do not set up the net where property damage could occur if the ball should go through the net. Use common sense, and all the same precautions as you would when playing baseball. Inspect the netting before and during each use. If any rips or holes are found – DO NOT USE! (Note: Nylon cable ties available from any hardware store can be used to repair small holes in the net – be aware of any new holes which may open – and if adequate repairs cannot be made, DO NOT USE!) Batter must wear NOCSAE Approved Batting Helmet. Make sure and disassemble the Spring Away Pro in stormy weather. The net could break or blow over and cause property damage. Make sure area around the sports net is clear of people except for the person using the net. Bodily injury could occur if proper safety precautions are not followed. Use with adult supervision.



# Parts List

A - Base Corner Connection

B - Base Straight Poles



C - Base Net Supports

D - Support Stakes

E - Fiberglass Side Poles

F - Pop Up Net

G - BONUS Carry Bag



Model# ZPR129





**Heater**  
SPORTS

95 West 650 South • St. George, Utah 84770 • PH: 800-492-9334 • PH: 435-656-1756 • Fax: 435-688-0741


# Assembly Instructions

- 1 - Place **Part A** (Base Corner Connection) and **Parts B** (Base Straight Poles) on the ground as shown in **Figure 1**. Slide **Parts B** into **Part A** aligning the push pins and lock in place - **Figure 2**



- 2 - Next take one **Part C** (Base Support) and insert into **Part B** locking the push pin in place. Do the same with the other **Part C** (Base Support) inserting **Part C** into **Part B** on the opposite side - **Figure 3**


**NOTE: Parts C will be pointing upward as seen in Figure 3.**




- 3 - Carefully unfold the pop up net **Part E** and locate the support pockets on the back side of the pop up net. Insert a **Part D** (Fiberglass Side Pole) into each side pocket on the pop up net - **Figure 4**.

- 4 - After inserting **Part D** into the side pocket on the pop up net, face the net forward and push the plastic end of **Part D** into the open steel tube of **Part C** - **Figure 5**. Do the same for the both sides.

**NOTE: The Spring Away Pro Pop Up Net will lean slightly backwards over the base support.**



**Figure 5**





# *Instructions To Fold the Pop Up Net*

- 1 - Remove the Pop Up Net from the **Support Base** and remove the **Fiberglass Side Poles**.
- 2 - Place the Pop Up Net flat on the ground and walk one corner diagonally to the opposite corner.



- 3 - Guide the right and left corners down on top of the coil.
- 4 - The right and left sides will coil into a circle and overlap on top of each other.



- 5 - Slide the Pop Up Net into the Carry Bag, place the Base parts and Fiberglass Side Supports into the interior pocket and zip closed.

**CAUTION: THIS SPRING STEEL FRAME IS DESIGNED TO POP OPEN AND SPRING CLOSED QUICKLY. DO NOT FOLD OR UNFOLD WITHOUT DIRECT ADULT SUPERVISION.**