

Heater™ **Perfect Swing**

Instructions For Use

IMPORTANT

DO NOT RETURN THIS PRODUCT TO THE RETAIL STORE WHERE PURCHASED. **CALL TOLL FREE: (800) 492-9334**

WARNING:


Improper use of this product can result in serious injury. Read and follow the instructions for the proper and safe use of the Perfect Swing. Always wear a helmet with a guard. Adult supervision is required. Inspect the ball, strap and shaft before each use for evidence of damage. Use practice bats with this product as Heater Sports does not accept responsibility for damage that may occur when using performance bats.

Heater®
SPORTS


Perfect Swing Instructions For Use

- 1 - Make sure area is clear of people or objects within reach of the batter or the person holding the Perfect Swing.
- 2 - The holder and the batter stand facing each other about 8' to 10' apart.
- 3 - If facing a right handed batter, the holder uses the safety strap on their left hand. If facing a left handed batter, the holder uses the safety strap on their right hand.
- 4 - The holder should hold the Perfect Swing with both hands and the arms extended. The batter should check the distance by holding the bat out towards the holder to judge the proper distance.
- 5 - The batter should focus on the real baseball cover as the target to make contact. Avoid unnecessary contact to the shaft that could case damage to the device.
- 6 - The holder should place the ball in the strike zone and provide a stationary target.
- 7 - The holder should hold the Perfect Swing firmly, but should not fight the momentum when contact is made.
- 8 - The holder may change the location of the ball in relation to the hitter, but should always make sure that the Perfect Swing is held parallel to the bat when contact is made.


CORRECT!



WRONG!



WRONG!



Heater[®]
SPORTS